

ASSEMBLY INSTRUCTIONS
LARGE OR SIGNATURE WEATHERVANE
 (with retaining hook)

BRASS DIRECTIONALS

COPPER BALL (LARGE)

SMALL ROD

BRASS RING

LARGE ROD (18")

ASSEMBLED VIEW

YOUR PACKAGE INCLUDES THE FOLLOWING PIECES:

- 1 Figure
- 1 Large Copper Ball
- 1 Set of Brass Directionals
- 1 Brass Ring
- 1 Small Steel Threaded Rod
- 1 Large Steel Rod (18")
- 1 Retaining Hook
- 1 Tube of Loctite®

1

10"

POSITION BRASS RING OVER LARGE ROD. TIGHTEN SET SCREW

2

APPLY A LINE OF LOCTITE® (supplied) ACROSS THE THREADS. (This small amount is all that's needed)

THREAD SMALL ROD INTO LARGE ROD. POSITION WRENCHES ON FLAT SPOTS. TIGHTEN FIRMLY.

TIP: You may save the remaining LOCTITE® for other uses. Simply reverse the cap for storage

3

SLIDE LARGE BALL DOWN ROD TO BRASS RING.

10"

4

INTERLOCK DIRECTIONALS, SLIDE ONTO ROD. TIGHTEN SET SCREWS.

(WEST GOES LEFT OF NORTH)

5

SLIDE WEATHERVANE AND RETAINING HOOK ONTO SMALL ROD SIMULTANEOUSLY. TIGHTEN SET SCREW.

Brass bottom of weathervane

Retaining hook.

APPLY COMMON GREASE TO ROD SO VANE WILL ROTATE FREELY.

FINAL STEP... SLIDE WEATHERVANE FIGURE ONTO SMALL ROD... ENJOY!